

Supported Maximum Configurations

Compatibility Guide

Contents

e-STUDIO305CP	3
e-STUDIO305CS/306CS	4
e-STUDIO385S/425S	5
e-STUDIO385P/470P	6
e-STUDIO525P	7

January 2017

Supported maximum configurations

The following tables provide information about the maximum possible configurations for each printer, option, and furniture stand.

Each row represents a supported maximum configuration. If an option is removed from a particular row, then the information would still indicate an acceptable configuration.

e-STUDIO305CP

The printer with optional drawers and adjustable printer stand:



The printer with optional drawers and swivel cabinet:



Placement	Optional 650-sheet drawer	Optional 550-sheet drawer
1		2
Desktop or adjustable printer stand	✓	
	✓	✓

Note:

- A maximum of two optional drawers may be configured with e-STUDIO305CP.

e-STUDIO305CS/306CS

The printer with optional drawers and adjustable printer stand:



The printer with optional drawers and swivel cabinet:



Placement	Optional 650-sheet drawer	Optional 550-sheet drawer
	1	2
Desktop or adjustable printer stand	✓	
	✓	✓

Note:

- A maximum of two optional drawers may be configured with e-STUDIO305CS and e-STUDIO306CS.

e-STUDIO385S/425S

The printer with optional drawers and adjustable printer stand:



The printer with optional drawers and swivel cabinet:



Placement	Optional 250- or 550-sheet drawer		
	1	2	3
Desktop or adjustable printer stand	✓		
	✓	✓	
	✓	✓	✓

Notes:

- Only one optional drawer may be configured with e-STUDIO385S.
- A maximum of three optional trays may be configured with e-STUDIO425S.

e-STUDIO385P/470P

The printer with optional drawers and adjustable printer stand:



The printer with optional drawers and swivel cabinet:



Placement	Optional 250- or 550-sheet drawer		
	1	2	3
Desktop or adjustable printer stand	✓		
	✓	✓	
	✓	✓	✓

Notes:

- Only one drawer may be configured with e-STUDIO385P.
- A maximum of three optional drawers may be configured with e-STUDIO470P.

e-STUDIO525P

The printer with optional tray, finisher, and caster base:



The printer with optional tray, finisher, and swivel cabinet:



Spacer:



Output Options

Printer configuration	4-bin mailbox			High-capacity output expander ¹	Output expander ²			Staple finisher ³	Staple, hole punch finisher
	Top	Middle	Bottom		Top	Middle	Bottom		
A					✓	✓	✓		
	✓				✓		✓		
	✓	✓					✓		
	✓						✓		
	✓		✓			✓			
		✓	✓		✓				
B	✓	✓	✓						
C					✓	✓			
			✓		✓				
	✓						✓		
D	✓	✓							
F	✓							✓	
G							✓	✓	
H				✓	✓				
I									✓
J								✓	
K					✓				
L				✓					
M	✓								

¹ The high-capacity output expander must always be at the bottom of a configuration.

² The output expander is the only option that can be placed on top of the high-capacity output expander.

³ The staple finisher must always be on top of a configuration.

Input Options

Notes:

- A maximum of four optional drawers may be configured with the printer.
- Always use a caster base when configuring the printer with an optional 2100-sheet drawer.

Printer configuration	Optional 250-sheet drawer ¹				Optional 550-sheet drawer ¹				Spacer ²		Optional 2100-sheet drawer ³	
	1	2	3	4	1	2	3	4	1	2		
A												✓
					✓	✓	✓					✓
					✓	✓						✓
					✓							✓
	✓	✓	✓									✓
	✓	✓										✓
	✓											✓
	✓				✓							✓
	✓				✓	✓						✓
	✓	✓			✓							✓
B					✓	✓	✓	✓				
					✓	✓	✓					
					✓	✓						
					✓							
	✓				✓	✓	✓	✓				
	✓	✓			✓	✓						
	✓	✓	✓		✓							
C	✓	✓	✓	✓								
	✓	✓	✓									
	✓	✓										
	✓											
	✓				✓	✓						
	✓				✓							
	✓	✓			✓							
D										✓		
					✓	✓	✓			✓		
					✓	✓				✓		
					✓					✓		
	✓	✓	✓							✓		
	✓	✓								✓		
	✓									✓		
D	✓				✓	✓				✓		

Printer configuration	Optional 250-sheet drawer ¹				Optional 550-sheet drawer ¹				Spacer ²		Optional 2100-sheet drawer ³
	1	2	3	4	1	2	3	4	1	2	
	✓				✓				✓		
	✓	✓			✓				✓		
	✓				✓				✓	✓	
					✓	✓			✓	✓	

¹ The optional 250- and 550-sheet drawers may be installed in any order.
² The spacer must be under the optional 250- or 550-sheet drawer and cannot be used with the 2100-sheet drawer.
³ The optional 2100-sheet drawer must always be at the bottom of a configuration.

Furniture

Notes:

- A maximum of four optional drawers may be configured with the printer.
- Always use a caster base when configuring the printer with an optional 2100-sheet feeder.

Placement	Optional 250-sheet drawer ¹				Optional 550-sheet drawer ¹				Optional 2100-sheet drawer ²	Spacer ³	4-bin mailbox	
	1	2	3	4	1	2	3	4				
Floor ^{4,5}					✓							✓
	✓	✓										✓
	✓											✓
Desktop ^{6,7}					✓	✓	✓	✓				✓
	✓	✓	✓	✓								✓
										✓		✓
Caster base ⁸									✓			✓
					✓	✓	✓					✓
	✓	✓	✓									✓
	✓				✓					✓		✓

¹ The optional 250- and 550-sheet drawer may be installed in any order.

² The optional 2100-sheet drawer must always be at the bottom of a configuration.

³ The spacer must be under the optional 250- or 550-sheet drawer and cannot be used with the 2100-sheet drawer.

⁴ An optional caster base may be used, but you can still safely operate the printer without it.

⁵ This may be configured with any output options.

⁶ An optional caster base must not be used when using the printer with desktop.

⁷ This may be configured with B and C input options and any output options.

⁸ This may be configured with any input and output options.